


REPAIR AND FINISHING



QUALITY SCHOOL



Learning objectives

The importance of proper repair techniques and materials

Identify product deficiencies and understand specifications





Why Do We Need to Repair Precast Products?

While our Goal is NO REPAIRS it doesn't always work that way!


Repairs are necessary for two main reasons:

1. Manufacturing imperfections
2. Handling damage





QUALITY SCHOOL



Repairs for Pipe (ASTM C76) and Manholes (ASTM C478)

“Pipe (& *manholes*) may be repaired, if necessary, because of imperfections in manufacture or damage during handling and will be acceptable if, in the opinion of the owner, the repaired pipe conforms to the requirements of this specification”





Repairs for Box Culverts


ASTM C1433 & C1577 Section 13

“Box sections shall be repaired, if necessary, because of imperfections in manufacture or handling damage and will be acceptable if, in the opinion of the purchaser, the repaired box section conforms to the requirements of this specification.”





QUALITY SCHOOL




Concrete is a Unique Construction Material

Almost every imperfection can be repaired if proper techniques and materials are used.





QUALITY SCHOOL



We must remember that:
Not everything should be repaired!

Basic Guidelines:


Will the product meet all the requirements after the repair?

Not only dimensional, but strength, durability and water-tightness as well.





QUALITY SCHOOL



Classification of Repairs

Structural

Performance

Cosmetic





Structural Repairs

Major defect repair

- Compromises structural integrity or designated use of the piece
- Needs to be inspected by qualified individual and documented
- If it can't be repaired, then reject it






QUALITY SCHOOL




STRUCTURAL - REPAIRABLE






QUALITY SCHOOL



STRUCTURAL - NOT REPAIRABLE





Performance / Functional Repairs

- Fix only what needs fixing – don't create more problems
- Use Approved Materials – strong, durable, good bond
- Final Appearance and Function is important






QUALITY SCHOOL




PERFORMANCE






QUALITY SCHOOL



CRITICAL PARTS OF A GASKET JOINT




OPENED POSITION

1. SMOOTH ENTRY TAPER






QUALITY SCHOOL




CRITICAL PARTS OF A GASKET JOINT





QUALITY SCHOOL



Cosmetic Repairs

Appearance is important!

Product appearance can be your:
**BEST SALESMAN OR
YOUR WORST SALESMAN**







Cosmetic Repairs

- Evaluate
- Minor defect repair
 - One that does not impact the functional use or expected service life of the product, routine (e.g. chips, bug holes)
 - Should have standard repair techniques and approved materials





QUALITY SCHOOL





Joint Repairs for Gasketed Joints


ASTM C443 - *Joints Using Rubber Gaskets*, Section 14

- Repair must be smooth, free of spalls, cracks, and imperfections that would adversely affect the performance of the joint (7.1.2)
- Circumferential length of a single area to be repaired shall not exceed one fourth of the inside diameter or equivalent diameter
- Circumferential length of several areas combined shall not exceed one half of the inside diameter or equivalent diameter
- Owner may require water-tightness testing to prove performance (13 psi, 10 minutes, straight)





QUALITY SCHOOL




Repair Materials





QUALITY SCHOOL



Repair Material Selection


Repairs should be made with like materials

Therefore: Repair concrete with concrete





QUALITY SCHOOL



Basic Repair Materials

Cement – Portland (can blend gray and white)

Sand – screened or Masons

Water





Patching Recipe Example

Large patches – use same concrete as the product was produced from or a stiff mixture of:

1 part cement: 3 parts sand (1:3 volume) + water

Smaller, more refined patches – very stiff paste

1 part cement: 2 to 2-1/2 parts sand + water

Water = clean water





Additives

Air entraining - as required for F/T

Water reducers – limit water content, shrinkage

Polymer admixtures – improve bond, cure





Cosmetic Repair Recipes

Cosmetic wipe – paintable

Fill porous bells and spigots – stiff consistency

- 1 part cement + water
- 1 part cement: 1 part sand + water (preferred)

Must be finished flush and not overdone





Bonding Grout

Bonding Grouts – paintable

- None
- 1 part cement + water
 - Immediately before patching

Avoid emulsifying bonding agents

- PVA (polyvinyl acetate)






QUALITY SCHOOL



PATCH BOND STRENGTH COMPARISON



BONDING AGENTS

* 1 PART CEMENT + MIX WATER
 ** 1 PART CEMENT + 1 PART SAND + MIX WATER
 MIXED WATER = 1 PART WATER + 1 PART BONDING AGENT





Pre-packaged Patch Materials

They have their place, especially in special applications

- very thin overlays
- need for quick setting
- need for high early strength
- special curing requirements
- non-shrink applications
- flowable materials, if specified.

Some are excellent, some are questionable.





Pre-packaged Materials

Read and follow ALL labeled directions exactly.


Reasons for failure:

- Too much water or re-tempering
- Wrong material formulation
- Improperly mixed
- Improperly applied
- Improperly cured.





QUALITY SCHOOL



Repair Methods





Structural Repair

- 1) Remove unsound concrete from area to be repaired
- 2) Check the position of reinforcing and/or add additional reinforcing as necessary
- 3) Form as necessary to reconstruct product to original shape
- 4) Dampen mating surface with water and let go surface dry (SSD) or apply bonding agent as required





Structural Repair

Make repair with original concrete or low slump repair mortar consisting of 1 part cement : 3 parts sand, depending on the size of repair and detail required

- Air entrain repair mortar when necessary
- Best to make repairs as soon after casting as practical


Tarp product or repaired area immediately after repair is completed to allow repair to pre-set.

Steam cure after pre-set is recommended.





QUALITY SCHOOL




Performance / Functional Repair

- 1) Remove unsound concrete from area to be repaired (if any)
- 2) Dampen mating surface with water let surface dry (SSD)
- 3) Make repair with very stiff repair mortar consisting of: 1 part cement (1-1/2 to 3) parts sand and water, depending on size or imperfection
- 4) Remove excess material (especially on joint sealing surfaces)
- 5) Cure properly to prevent premature drying and shrinkage





QUALITY SCHOOL



FINISH THE JOB - Check your work

Dimensional Tolerance – Product Specifications


Dimensional Tolerance – Joint Tightness and Function

Appearance






QUALITY SCHOOL



GO, NO-GO GAUGE




ACPA CERTIFICATION PROGRAM REQUIRES THAT
ALL GASKET SEALING SURFACES BE 100%
DIMENSIONALLY CHECKED

SIDE VIEW





QUALITY SCHOOL



Defect Review





Defect Review – Pipe (C76) and Manhole (C478)

Rejection due to cracking:

- Fractures or cracks passing through the wall, except for a single end crack that does not exceed the depth of the joint
- Damaged or cracked ends where such damage would prevent making a satisfactory joint
- Any continuous crack having a surface width of 0.01” or more for a length of 12” or more (unloaded)





Defect Review – Box Culverts


Rejection due to cracking, **ASTM C1433 & C1577**

- Fractures or cracks passing through the wall, except for a single end crack that does not exceed the depth of the joint





QUALITY SCHOOL



Defect Review – Pipe (C76) and Manhole (C478)

Rejection due to material or production defects

- Defects that indicate proportioning, mixing, and molding not in compliance or surface defects indicating honeycombed or open texture that would adversely affect the function of the product
- The ends of the piece are not normal to the walls and center line of the pipe, and not within the limits of variations given in the standards





Defect Review – Box (ASTM C1433 & C1577)

Rejection due to material defects

- Defects that indicate mixing and molding not in compliance with 9.1, or honeycombed or open texture that would adversely affect the function of the box sections





Defect Review – Box (C1433 & C1577) (cont.)


Rejection due to material or production defects

- Abnormalities in the ends of the box sections to the walls and center line of the box section, within the limits of variations given in Section 11, except where beveled ends are specified, and
- Damaged ends, where such damage would prevent making a satisfactory joint.





QUALITY SCHOOL




Repairable or
Non-Repairable ?





QUALITY SCHOOL



Defect Review

You are now the QC Inspector

Do the following products:

- Meet specifications?
- Can they be repaired?
- Or should they be rejected?

















06/16/2015



06/16/2015



06/16/2015











06/16/2015



06/16/2015

1890 ALOK
42" TACP C.



















QUALITY SCHOOL

